

SPEKURA

Installation instructions:

Turn off power to the receptacle before proceeding.

1. Prepare Mount

Remove the wall plate. Loosen the upper receptacle screw. Place the mount tab between the receptacle and wall. Center the mount and verify alignment with the wall plate temporarily installed.

2. Install Support

Mark the upper mounting slot location. Remove the mount and install the included wall anchor. Reinstall the mount and install the upper mounting screw. Adjust as needed for proper alignment.

Note: A Command™ Strip may be used instead of drilling.

3. Secure Mount

Tighten the upper receptacle screw firmly. Reinstall the wall plate.

4. Route Cable

Feed the HomePod Mini cable through the upper opening. Wrap excess cable neatly inside the mount, keeping each loop tight against the inner walls. Do not kink the cable. Route the USB-C connector through the lower opening.

5. Install HomePod mini

Press the HomePod Mini firmly into the mount and ensure it is centered.

6. Connect Power

Plug the power adapter into the receptacle. Connect the USB-C cable to the power adapter. Make any final cable adjustments.

Designed with intent.