


SPEKURA



Installation instructions:

Position template and level in place.

Mark hole centers using a pushpin or center punch.

Drill holes using a 3/16" drill bit.

Insert anchors flush to wall.

Align mount with installed anchors and secure firmly to wall using included screws.

For integrated charger configuration:

Insert the official Sonos wireless charger into mount from the front until fully seated.

Route charging cable through rear cable channel.

For cable-only installation:

Route the official Sonos right-angle USB-C cable through bottom cable channel and connect cable to Sonos Roam before placing speaker onto mount.